



S'il vous plaît utiliser le commerce pour envoyer votre commande.

Departement: Adapteur union mâle-mâle BSP - Mètr. - CEA		
Nr	Qté	Description
NBM M-M R16-M38		UNION DOUBLE MALE-MALE BSPP 1" - M38
NBM M-M R08-M14		UNION DOUBLE MALE-MALE BSPP 1/2" - M14
NBM M-M R08-M16		UNION DOUBLE MALE-MALE BSPP 1/2" - M16
NBM M-M R08-M18		UNION DOUBLE MALE-MALE BSPP 1/2" - M18
NBM M-M R08-M20		UNION DOUBLE MALE-MALE BSPP 1/2" - M20
NBM M-M R08-M22		UNION DOUBLE MALE-MALE BSPP 1/2" - M22
NBM M-M R08-M27		UNION DOUBLE MALE-MALE BSPP 1/2" - M27
NBM M-M R04-M12		UNION DOUBLE MALE-MALE BSPP 1/4" - M12
NBM M-M R04-M14		UNION DOUBLE MALE-MALE BSPP 1/4" - M14
NBM M-M R04-M16		UNION DOUBLE MALE-MALE BSPP 1/4" - M16
NBM M-M R04-M18		UNION DOUBLE MALE-MALE BSPP 1/4" - M18
NBM M-M R04-M20		UNION DOUBLE MALE-MALE BSPP 1/4" - M20
NBM M-M R04-M22		UNION DOUBLE MALE-MALE BSPP 1/4" - M22
NBM M-M R02-M10		UNION DOUBLE MALE-MALE BSPP 1/8" - M10
NBM M-M R02-M12		UNION DOUBLE MALE-MALE BSPP 1/8" - M12
NBM M-M R02-M14		UNION DOUBLE MALE-MALE BSPP 1/8" - M14
NBM M-M R12-M22		UNION DOUBLE MALE-MALE BSPP 3/4" - M22
NBM M-M R12-M26		UNION DOUBLE MALE-MALE BSPP 3/4" - M26
NBM M-M R12-M27		UNION DOUBLE MALE-MALE BSPP 3/4" - M27
NBM M-M R12-M30		UNION DOUBLE MALE-MALE BSPP 3/4" - M30
NBM M-M R06-M12		UNION DOUBLE MALE-MALE BSPP 3/8" - M12
NBM M-M R06-M14		UNION DOUBLE MALE-MALE BSPP 3/8" - M14
NBM M-M R06-M16		UNION DOUBLE MALE-MALE BSPP 3/8" - M16
NBM M-M R06-M18		UNION DOUBLE MALE-MALE BSPP 3/8" - M18
NBM M-M R06-M20		UNION DOUBLE MALE-MALE BSPP 3/8" - M20

NBM M-M R06-M22		UNION DOUBLE MALE-MALE BSPP 3/8" - M22
--------------------	--	--